DARPA Sensors for Immune Building Program

Dr. Wayne A. Bryden Special Projects Office







This document was cleared by DARPA on December 7, 2005 Distribution Statement "A" (Approved for Public Release, Distribution Unlimited).



Problem Conception and Program Development




- The SIB Program develops point and stand-off sensors to enable the protection of military facilities and the associated military and civilian work forces within those facilities
- Develop sensors with:
 - Higher sensitivity
 - Lower false alarm rate
 - Broader agent coverage
 - Faster operation
 - Lower cost
- Sensors developed under the SIB Program will be transitioned to replace current sensors used for building protection



Building Protection Concept







Sensor Needs and Impact



A Standoff chemical detectors

 Reduces filtration and operating costs by allowing on-demand filtration/neutralization of external threats

B) Fast, cheap, biological triggers

- Detect at lower m_{rel} (better sensitivity)
- Improved sensor layout with lower-cost sensors
- Lower building protection operating costs (low false alarm rate)

C) Fast, cheap, chemical triggers

- Detect TICs/unfilterables
- Detect at lower m_{rel} (better sensitivity)
- Lower building protection operating costs (low false alarm rate)

D Fast biological confirmatory sensors


- Enables use of evacuation and personal protective equipment (PPE)
- Lower building protection operating costs

E Fast chemical confirmatory sensors

- Enables use of evacuation and PPE
- Lower building protection operating costs

(F) Laboratory analysis

- Improved "Gold Standard" testing
- Detect-to-treat capability





SIB Program Sensors



(A) Standoff chemical detectors

 JAGUAR/SAGE: standoff, passive IR hyperspectral detection & identification of airborne chemicals for wide area surveillance of fixed sites

B Fast, cheap biological triggers

- Inexpensive Particulate Aerosol Sensor (IPAS): a bio-trigger based on particle counting/sizing and designed for wide proliferation with low initial purchase cost and low operating expenses
- Low Cost Particle Counter (LCPC): makes modification of the sampling and optical systems of existing particle counters to permit >2 months MTBM

Fast, cheap chemical triggers

• <u>Photoionization Detector:</u> a ganged photoionization detector to rapidly detect the presence of chemical agents and provide discrimination against background

D Fast biological confirmatory sensors

- <u>AP MALDI MS/MS</u>: Atmospheric Pressure Matrix-Assisted Laser Desorption/Ionization tandem Mass Spectrometer; collect sample; rapidly treat with enzyme; measure peptides with AP-MALDI MS/MS; search database for peptide matches for organism detection
- Rapid Detection of Virions in Air: collect air sample on filter tape; apply large amount of two brightly labeled antibodies; use video imaging to detect binding
- Rapid Autonomous Bioagent Detection: cantilever bridged with single strand DNA (or other); when complimentary strand binds, cantilever deforms and current through cantilever changes indicating binding; clean probe by applying current that scales with stringency of binding



SIB Program Sensors (cont.'d)



E Fast chemical confirmatory sensors

- Point FTIR: develop field-hardened commercial prototype of FTIR (including multipass gas cell);
 incorporate SAGE algorithm for rapid identification of CWAs and TICs in presence of clutter
- Improved Differential Mobility Spectrometer (I-DMS): develop an optimized differential mobility sensor with improved sensitivity and specificity, while minimizing the effects of variable humidity and pressure
- <u>Thermal swing Pre-concentrator (TSP):</u> develop a "digital GC" using electrospray polymers coupled to piezoelectric heater/cooler module; couple with I-DMS
- Integrated Cavity Optical Sensor (ICOS): develop extremely long pathlength IR absorption system operating in the LWIR
- <u>L-PAS/Freedom:</u> develop prototype photoacoustic spectrometer operating in LWIR with frequency selectable 13CO2 laser

Laboratory analysis

- Rapid Yersinia pestis Viability: optimization of culturing growth parameters and reduction in the time required to determine viability of biological warfare agents
- <u>Viral Viability and Toxin Activity:</u> develop methods for the rapid detection of biological activity in a sample containing active toxin or viable virus
- Rapid Autonomous Integrated DNA Detection System (RAIDDS): reduce the time required to detect, identify, and confirm the presence and viability or activity of biological warfare agents.



SIB Program Schedule



